

STUN-CUFF™

MODEL MAGNUM

OPERATION MANUAL – Please read before using this equipment.

Please note: The batteries have been disconnected for shipping. Using the small screw driver (included) remove battery covers and reconnect plugs.

REMOTE CONTROL:

1. The Remote Control can be programmed to operate any STUN-CUFF.
2. To change Remote Control code: Press “ST” button for (2) two seconds until hearing (2) two tones and seeing green light on remote. Enter the code/serial number from front of STUN-CUFF. (Located on bottom right corner.) Then press “ST” button to save change. There will be one tone and the green light will go out.

Please note: Input the code exactly. If you make a mistake press the “CL” button and re-enter code.

3. Administering electric shock: The STUN-CUFF has a (2) two button trigger safety system. To fire the STUN-CUFF, the “ON” button must be pressed first then within (10) ten seconds the “FIRE” button must be pressed or the procedure must be repeated.
4. Testing: Press the “ON” button and the “Green” power light on the STUN-CUFF will light. This means the STUN-CUFF is receiving the proper code. However, this will not initiate a shock.
5. Low batteries: If power is weak when pressing ST, CL or ON button, a red light will come on and sound (3) tones and then complete function. The red light will go out in (10) ten seconds after releasing the button and will enter power saving mode. (Normally the STUN-CUFF and remote controller enter power saving status after (10) ten seconds.

STUN-CUFF:

1. ON/OFF:
 - A. Turn on: Pass the bottom of the remote control over the LED light area of the STUN-CUFF. The Green power light will come on, press the “ON” button on the remote control within (12) twelve seconds or repeat procedure. The Green light will flash quickly then go in to power saving mode. The Green LED light will flash every 2-3 seconds to show it is in the “ON” mode. If power is low the Green light will be Red.

- B. Turn off: Press the “ON” button of remote controller for (3) three seconds. The Green power light on the STUN-CUFF will flash (2) two times and turn cuff off.
2. Testing: The Green power light on the STUN-CUFF will light when pressing the “ON” button, this means the correct code has been entered. This will not activate an electrical shock. When the “ON” button is released the Green light will go out. Do not press the “ON” button for more than (3) three seconds as this will turn the STUN-CUFF off.
 3. Firing: To trigger an electrical shock press the “ON” button first, then within (10) ten seconds press the “FIRE” button. This will initiate a 2-3 second shock. The “FIRE” button can be held down for a longer shock. The shock will continue for 2-3 second after release. Another shock can be given if done in less than (10) ten seconds. When the electricity is weak the Green light will be Red.

Charging Base:

Attach power cord to base and plug in, use on/off button on side of charging base. The LED lights will go from red when charging to green when charged. When charging is complete turn power to base off.

Safety Instructions:

1. Program remote control to STUN-CUFF before turning on.
2. Keep clear of electrical points on STUN-CUFF.
3. Stun only as long as needed for compliance.
4. Do not disassemble any part of STUN-CUFF unit. (Except for battery connection.)

Features:

Range 100 yards, water/impact resistant, uses standard handcuff key, holster.

LIMITED 1 YEAR WARRANTY

This product is warranted by Stun-Cuff against manufacturing defects in material and workmanship under normal use for 1 year from the date of purchase from Stun-Cuff. EXCEPT AS PROVIDED HEREIN. STUN-CUFF MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, STUN-CUFF SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, PERSONAL INJURY, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR ANY OTHER DAMAGES NOT MENTIONED HEREIN.